

CLIMBING WALL INSTALLATION ADDENDUM

Pursuant to the climbing wall instructions, the panels are attached to the wall in 4 separate sections in lieu of one complete panel. There are 4 mounting holes total per section located in each corner. Use the 5/16 concrete screw for mounting. Each section is numbered 1-4. Begin by installing section #4 resting above the wood block on the floor. Follow vertically with section #3, section #2, and finally section #1 which will be located at the top of the wall. The #1 panel is noted with “top”. This is to ensure the buckles are installed in the correct direction.

For 10' walls, please install section #5 above the top section #1.