

ALERT WORKS Model EAR-10 “ALERT OFF” Option

Your Alert Work’s EAR-10 Emergency Alert Weather Radio allows you to program the radio to silence selected event codes in your area to minimize annoyance.

- Press **MENU** button to open menu options
- Press **UP** directional arrow to scroll through menu options until “**ALERTOFF**” is displayed
- Press **SELECT**
- Press the **UP/DOWN** directional arrow to select the event code that you wish to silence
- Press the **LEFT** or **RIGHT** directional arrow to set the selected event code to “**ON** or **OFF**”
- Press **MENU** to exit the programming mode

<u>EVENT CODE</u>	<u>DESCRIPTION</u>
ADR	Administrative Message
AVA	Avalanche Watch
AVW	Avalanche Warning
BWW	Boil Water Warning
BZW	Blizzard Warning
CAE	Child Abduction Emergency
CFA	Coastal Flood Watch
CFW	Coastal Flood Warning
DBA	Dam Watch
DMO	Practice/Demo
DSW	Dust Storm Warning
EVA	Evacuation Watch
FFA	Flash Flood Watch
FFS	Flash Flood Statement
FFW	Flash Flood Warning
FLA	Flood Watch
FLS	Flood Statement
FLW	Flood Warning
FRW	Fire Warning
FSW	Flash Freeze Warning
FZW	Freeze Warning
HLS	Hurricane Statement
HUA	Hurricane Watch
HWA	High Wind Watch
HWW	High Wind Warning
IBW	Iceberg Warning
NAT	National Audible Test

NIC	National Information Center
NMN	Network Notification
NPT	National Periodic Test
NST	National Silent Test
POS	Power Outage Advisory
RMT	Required Monthly Test
RWT	Required Weekly Test
SMW	Special Marine Warning
SPS	Special Weather Statement
SVA	Severe Thunderstorm Watch
SVR	Severe Thunderstorm Warning
SVS	Severe Weather Statement
TOA	Tornado Watch
TOE	911 Telephone Outage Emergency
TRA	Tropical Storm Watch
TXB	Transmitter Back Up On
TXF	Transmitter Carrier Off
TXO	Transmitter Carrier On
TXP	Transmitter Primary On
WFA	Wild Fire Watch
WSA	Winter Storm Watch
WSW	Winter Storm Warning
??A	Unrecognized Watch
??E	Unrecognized Emergency
??S	Unrecognized Statement